



## **Multi-Function Sampling System**

For Restricted & Closed Tank  
Applications

**The Multi-Function Sampling System for Restricted & Closed Tank Applications is available in both 3/4 liter capacity and 1/2 liter capacity.**

Each Sampling System comes complete with the **500' cotton cord spool, appropriate vapor valve storage tube, gauging bag, MMC Collar, Hermetic adapter and the Multi-Function Sampler.**

The Multi-Function Sampler allows the operator to choose the type of sampler needed by selecting one of the various tops and bottoms included in the sampling kit. For example, for running samples, the user would choose the Adjustable Neck top. For zone samples, the user would choose the zone bottom.

The Multi-Function sampler may also be used for RVP sampling applications. By using the specially designed spring loaded bottom valve and the RVP trip funnel, the user is able to transfer gasoline without losing vapor pressure during the transfer process.

- For closed & restricted sampling on vessels with inert gas pressure.
- Designed to fit MMC or Hermetic vapor control valves.
- Restricts escape of vapors into the atmosphere.
- Meets API sampling requirements for:
  - Running samples
  - All level samples
  - Spot samples
  - Zone samples
  - Bottom samples
  - RVP samples
- Ideally suites for oil inspectors
- Safer for personnel and environment
- Simple and safe to use



**Includes FREE  
gauging bag!!**

<b>Catalog No.</b>	<b>Description</b>
1050HTS-RVP	3/4 Liter Multi-Function RVP Sampler
1050HTS	3/4 Liter Multi-Function Sampler